

## Upgrade Instructions for M-ATA

Following are step-by-step instructions for upgrading the M-ATA Unit from the webpage. These instructions assume that you have acquired the IP address from the built-in IVR and have accessed the webpage.

1. Download the code and extract it to a folder on your desktop. For the sake of example we'll use the following folder: C:\Documents and Settings\patton\Desktop\MATA. And our code is named mata\_0407.r0.
2. Install and start-up a TFTP server on your local PC. I use the freeware Pumpkin, there's also another product made by Solar Winds. Set the default download directory within your TFTP server settings to be the directory you extracted the MATA code to, our example would be C:\ Documents and Settings\patton\Desktop\MATA
3. Identify your local IP address by going to Start -> Run -> cmd. Type in ipconfig and remember the IP address you were assigned. For the sake of example, my IP address is 10.10.22.23.
4. Access your MATA's webpage. On the left hand side click System → Manual Upgrade. Input your IP address that you located in step 3. Our example uses 10.10.22.23. Than input the name of the file that you extracted in step 1. Our example uses mata\_0407.r0.
5. Click Start TFTP Download. The unit will ask you if you're sure that you want to begin the upgrade, click Ok. The upgrade process will now begin.
6. When it completes the unit will ask you if you want to reset the unit into the main application or into the download application. Click reset unit into main application.
7. Your unit has now been upgraded to the new version of code.